⧖ — normal bow ⧗ — flipped bow

••

V+⧖ — analog volume
V+⧗ — digital volume
A+⧖ — algorithm
A+⧗ — variation
R+⧖ — common release
R+⧗ — percussive release
R+**T** — common release type
S+⧖ — FX mix
S+⧗ — FX time
S+**T** — FX type
T+⧖ — keyboard transpose
T+⧗ — flip transpose
P+⧖ — load preset
P+⧖+**A** — save preset
P+⧖+**V** — save preset+volume
P+⧗ — polyphony

"Q" — quantize
"Q"+⧖ — quantize strength
"Q"+**P**+⧖ — timbral kbd curve
"P" — percussion
"P"+⧖ — percussion sensitivity
"P"+**P**+⧖ — notes kbd curve
"P"+**P**+⧗ — tilt sensitivity
"Q"+**"P"** — duophonic
◿+**P**+**T** — pedal type
R+**S** — cut decay
A+**T**+⧖ — master tune
"Q"+**"P"**+**V** — lock sensors
V+**A** — calibration

••

USB stick drive
S+(**QP**)+**A** — save presets
P+(**QP**)+**A** — load presets
U?+**A** — firmware update